



GAMO Item #	PARTS NO. on Explored View	DESCRIPTION	Quantity
PR776-1-01	1-01	FRAME	1
PR776-1-07	1-07	FRAME COVER	1
PR776-1-12	1-12	SAFETY	1
PR776-1-13	1-13	SAFETY PARTS	1
PR776-1-14	1-14	SAFETY LEVEL	1
PR776-1-15	1-15	HAMMER SPRING SEAT	1
PR776-1-17	1-17	TRIGGER CONNECTOR	1
PR776-1-18	1-18	MAG. STOPPER	1
PR776-1-24	1-24	PELLET MAG.	1
PR776-1-26	1-26	BARREL ADAPTER	1
PR776-1-27	1-27	VALVE SEAL	1
PR776-1-28	1-28	FRONT BARREL TIP	1
PR776-1-29	1-29	INTERNAL BARREL	1
PR776-1-30	1-30	HAMMER PUSHER SPRING	1
PR776-1-34	1-34	INTERNAL BARREL SPRING	1
PR776-1-35	1-35	SAFETY PARTS SPRING	1
PR776-1-36	1-36	REAR SIGHT SPRING	1
PR776-1-38	1-38	TRIGGER CONNECTOR SPRING	1
PR776-1-39	1-39	SPRING BAR	2

GAMO Item #	PARTS NO. on Explored View	DESCRIPTION	Quantity
PR776-1-40	1-40	AXIS	1
PR776-1-42	1-42	ADJUSTED SCREW	1
PR776-1-43	1-43	SCREW SIGHT COMBINATION	1
PR776-1-44	1-44	SCREW FRAME COVER	4
PR776-1-45	1-45	SCREW SAFETY	1
PR776-1-46	1-46	SCREW CHAMBER COMBINATION	1
PR776-1-49	1-49	SAFETY SPRING	1
PR776-1-50	1-50	KNOB FIXING BLOCK	1
PR776-1-51	1-51	PUSHER SPRING STOPPER	1
Sub-Assemblies			
PR776-1C	1C	DRUM COMBINATION	1
PR776-1B	1B	SIGHT COMBINATION	1
PR776-1E	1E	TRIGGER COMBINATION	1
PR776-3	3	OUTER BARREL COMBINATION	1
PR776-4	4	HAMMER COMBINATION	1
PR776-7	7	CHAMBER COMBINATION	1
PR776-8A	8A	PIERCING LEVEL SCREW COMBINATION	1
PR776-GRIP	1-04 & 1-05	GRIP COMBINATION	1